

# **SAFETY INFORMATION**

These instructions should be read carefully prior to any installation and retained after completion for further reference and maintenance.

Please give these instructions to the building owner/occupier after installation.

#### **IMPORTANT**

This unit should be installed to current IEE wiring regulations, if in doubt please consult a qualified electrician.

#### IMPORTANT SAFETY

**1.** Before installation or maintenance, ensure that the

mains supply to the downlight is switched off and the circuit supply fuses are removed or the circuit breaker is turned off.

2. The person carrying out the installation is to check and verify that the total load on the circuit, including that of this downlight does not exceed the rating of the circuit cable, fuse or circuit breaker.

# **INSTALLATION INSTRUCTIONS**

#### FOR RECESSED DOWNLIGHTS

- 1. Only install the downlight on a surface with a minimum thickness of 5mm.
- **2.** Remove the outer trim by pushing the inner fitting from the back, discard this trim as it is not required for recessed installation. (Only For AT9011)
- **3.** Cut a hole in the surface to accommodate the downlight.
- **4.** Push the downlight into the hole.
- **5.** Connect the downlight supply lead to the low voltage driver. This downlight must not

be connected directly to the 230 volt supply.

**6.** Ensure the downlight is not covered with insulating or similar material.

# FOR SURFACE MOUNT DOWNLIGHTS

- 1. Remove the outer trim by pushing the inner fitting from the back.
- **2.** Mount the outer trim on to the selected mounting surface, using two screws.
- **3.** If required, drill a 6mm hole, within the footprint of the mounted outer trim so the supply leads can be fed out behind the fitting.
- **4.** Push the downlight into the outer trim, taking care to not trap the supply leads.
- **5.** Connect the downlight supply lead to the low voltage driver. This downlight must not be connected directly to the 230 volt supply.

# **LAMP TYPE**

3 X LED, Not replaceable (Life span 50,000 hours approx)

### **GUARANTEE**

Your Atom LED Cabinet Light Fitting is guaranteed for 3 years from the date of purchase. Please retain receipt as proof of purchase.

# PLEASE KEEP THESE INSTRUCTIONS SAFE FOR FUTURE REFERENCE

